



The Channel Strip Local Mode

You can also use the 12 Encoders of the Fader Module to edit Aux /Studio Send level and parameters, Gain, Pan, Plug-Ins and the EQ for the selected channel.

Single Channel View / Local Mode

Press FDR or ENC SELECT, or use TOUCH - SELECT for the faders. To edit any channel parameter, please press one of the following keys:

AUX
PANNING
PLUG-IN 1-8
EQ.

If you can edit more than 12 parameters, please also use PAGE for more details.

AUX (STUDIO)

Page 1

Aux Send level 1-8;
 Main Pan; Main-FR;
 Gain; Phase

Page 2

Studio Send level
 1-3; Main Pan; Main-
 FR; Gain; Phase

Description

Aux Send level 1-8.
 Press the Edit
 Encoders to set the
 corresponding Aux
 Send to On or Off.

Studio Send level 1-3.
 Press the Edit
 Encoders to set the
 corresponding Studio
 Send to On or Off.

PANNING

Page 1

X-Pos.; Y-Pos.; LFE-
 Gain; Center; Front-
 Divergence; Rear-
 Divergence; F/R-
 Divergence.

Description

For movements you
 should also use the
 Motor-Joystick
 (Option)

PLUG-IN 1-8

Page 1 - 99

You can edit up to
 1188 parameters!

Description

Select 1-4 to press the
 buttons 1/5 -4/8 once,
 select 1-8 to press the
 buttons 1/5 -4/8 twice.

EQ

Page 1

You have all EQ
 parameters on your
 hands.

Description

Gain 1; Freq.2; Q 1;
 Gain 2; Freq.2; Q 2;
 Gain 3; Freq.3; Q 3;
 Gain 4; Freq.4; Q 4;

Multi Channel View / Global Mode

You want to edit Gain for all channels at the same time? The Global Mode is the right solution here. Using the EDIT dials, you can change the respective parameter setting for each channel. The display above each dial gives you optical feedback.

Please press one of the following keys:

PAN
GAIN
STD 1-4
AUX 1-8

If you can edit more than 12 parameters,

PAN

Page 1

Pan
 (Press once)

Description

Pan functionality for
 12 channels at the
 same time

GAIN

Page 1

Gain
(Press twice)

Description

Gain functionality for
12 channels at the
same time

STD 1-4

Page 1

Description

Select 1-4 to press the
buttons 1/5 -4/8 once.

Level; press the
Encoder to switch on.

Page 2

On

Page 3

Pre

Page 4

Pan

Page 5

Bypass

AUX 1-8

Page 1

Description

Select 1-4 to press the
buttons 1/5 -4/8 once,
select 5-8 to press the
buttons 1/5 -4/8 twice.

Level; press the
Encoder to switch on.

Page 2

On

Page 3

Pre

Page 4

Pan

Page 5

Patch

Page 6

Bypass